




BT-CNF90

BISSETT™
DRIVEN BY PROFESSIONALS

ITEM	PARTS NO	PARTS NAME
101	BTP2040101-05020-2	HEX.SOC.HD.BOLT
102	BTP2040201-06030-0	FLAT WASHER
103	BTP113BG-1084701-1	EXHAUST DEFLECTOR GASKET
104	BTP2040104-03010-0	HEX.SOC.HD.SCREW
105	BTP2040101-04121-0	HEX.SOC.HD.BOLT
106	BTP11369-1085201-1	CAP
107*	BTP11370-1080001-1	SEAL
108	BTP11360-1080001-1	COMPRESSION SPRING
109	BTP11368-1080001-2	HD.VALVE PISTON
110	BTP11399-1080001-1	COLLAR
111	BTP2041101-05021-0	O-RING
112*	BTP2041109-07030-0	O-RING
113*	BTP11302-0864701-1	CYLINDER CAP SEAL
114	BTP2041104-05010-0	O-RING
115*	BTP11350-0370004-1	PISTON RING
116	BTP11204-1080001-2	DRIVER UNIT
117	BTP11322-0370002-1	CYLINDER RING
118	BTP11320-1080002-3	CYLINDER
119	BTP2041101-06010-0	O-RING
120	BTP11321-1080002-1	CYLINDER SPACER
121	BTP2041101-09020-0	O-RING
122*	BTP11327-1084701-1	BUMPER
124	BTP1135G-0464701-1	RUBBER PAD
201	BTP2041104-02060-0	O-RING
202	BTP11374-0860001-1	PLUNGER CAP
203	BTP2041100-02050-0	O-RING
204	BTP2041100-01070-0	O-RING
205	BTP1133S-0860001-1	VALVE PLUNGER
206	BTP2041100-01030-0	O-RING
207	BTP11376-0860001-1	SPRING
208	BTP2041108-01020-0	O-RING
209	BTP11375-1080001-2	PLUNGER
210	BTP11373-0860001-1	TRIGGER VALVE HEAD
210A	BTP11226-1080001-2	TRIGGER VALVE UNIT
211	BTP11329-0860001-1	PIN
212	BTP1137A-0860002-1	COVER-PLUNGER
213	BTP2041104-02070-0	O-RING
214	BTP2041100-01050-0	O-RING
215	BTP2040401-05150-0	SPIRAL PINS

ITEM	PARTS NO	PARTS NAME
216	BTP2040401-05110-0	SPIRAL PINS
217	BTP2040401-05160-0	SPIRAL PINS
218	BTP11224-0764701-1	TRIGGER UNIT
219	BTP11376-0370001-1	SPRING
301	BTP11230-1085203-1	GUN BODY UNIT
302	BTP11346-1081304-2	END CAP
303	BTP1135V-0000023-1	AIR PLUG
304	BTP1133D-0370002-1	HOOK
306	BTP2041107-02030-0	O-RING
401	BTP2041104-07050-0	O - RING
402	BTP11382-1084701-3	NOSE PIECE
403	BTP2040101-05030-2	HEX.SOC.HD.BOLT
404*	BTP2041100-01090-0	O - RING
405	BTP11364-1014701-2	FEED PISTON
406*	BTP2041100-03051-0	O - RING
407	BTP11367-1080001-1	PUSHER SPRING
408	BTP11367-1080002-1	PUSHER SPRING
409	BTP1134W-0860001-1	FEED BUMPER
410	BTP11366-0954701-1	FEED PISTON CAP
411	BTP2040300-02010-0	C - RING
412	BTP11310-0254702-2	LOCK LEVER
413	BTP11311-1030001-1	LATCH SPRING
414	BTP11361-1084701-2	DOOR
415	BTP1131K-1034701-1	PIN
416	BTP1139F-1084701-1	PIN - NAIL STOP
417*	BTP1135H-0860001-1	PU RETAINER
418	BTP1131D-0460001-1	URETHANE RETAINER
419	BTP11337-0264702-1	SAFETY SPRING
420	BTP1139D-1084701-1	NAIL STOP
421	BTP11362-1084701-1	DOOR SHAFT PIN
422	BTP11331-1084701-1	SAFETY A
423*	BTP11339-0764702-1	PROTECTIVE CASING
424	BTP2040302-24010-0	E-RING
425	BTP11338-1084702-1	SAFETY GUIDE
426	BTP11337-1080001-1	SAFETY SPRING
427	BTP2040400-04050-0	SPRING PIN
428	BTP11256-1084701-1	SAFETY B UNIT
429	BTP11393-0761101-2	ADJUST AXIE
430	BTP1137A-1084701-1	SAFETY COVER

ITEM	PARTS NO	PARTS NAME
431	BTP11393-1084701-1	ADJUST ROD
432	BTP2041102-01050-0	O - RING
433	BTP11354-1084701-1	MAGAZINE CASE
434	BTP1134M-0864701-1	SPRING BASE
435	BTP1139B-1084701-1	WASHER
436	BTP1136R-0864701-1	MAGAZINE SHAFT PIN
437	BTP11328-0970001-2	PULL SPRING
438*	BTP11356-1084701-1	NAIL HOLDER
439	BTP1134N-1014701-1	SPRING BASE A
440	BTP11355-1080001-1	MAGAZINE COVER
441	BTP11358-1084701-1	NAIL STOP
442	BTP1133C-1080001-1	STOPPER FINGER SPRING
443	BTP11359-1084701-1	PIN-NAIL STOP
444	BTP11306-1084701-1	FEED FINGER
445	BTP11365-0864701-1	PIN FEED PISTON
446*	BTP11307-0864701-1	FEED FINGER SPRING
447	BTP2040401-05080-0	SPIRAL PINS
448	BTP1134R-1084701-1	SPRING COVER
449	BTP2040501-04010-0	BOLT CAP
450	BTP2040101-04120-0	HEX.SOC.HD.BOLT
451	BTP2040202-04010-0	FLAT WASHER
452*	BTP11383-1080001-1	MUZZLE PROTECTOR
453	BTP1135U-1010001-1	PROTECTOR WASHER
454	BTP1134B-0864701-1	DUST SHIELD PLUG
455	BTP2040101-04051-0	HEX.SOC.HD.BOLT
456	BTP11337-1080002-1	SAFETY SPRING

The following parts are included in the BTPCNF90KIT1 parts kit:

110	112	114	117	121	404	409
111	113	115	119	125	406	

The following parts are included in the BTPCNF90KIT2 parts kit:

201	203	205	207	209	211	213
202	204	206	208	210	212	214