



BT-CNR45

ITEM	PARTS NO	PARTS NAME
101	BTP1137V-0464701-1	DEFLECTOR BOLT(3M2353)
102	BTP11371-0254702-1	DEFLECTOR
103	BTP1135G-0464701-1	RUBBER PAD
104	BTP1132T-0460001-1	MUFFLER
105	BTP2040101-03110-0	HEX.SOC.HD.BOLT
106	BTP1135R-0254706-1	PROTECTIVE CUSHION
107	BTP11397-0254712-2	GUIDE COVER
108	BTP11369-0255201-1	CAP
109*	BTP11370-0250005-1	SEAL
110	BTP11360-0460001-3	COMPRESSION SPRING
111*	BTP2041104-04070-0	O - RING
112	BTP11368-0460004-1	HD.VALVE PISTON
113*	BTP2041109-05030-0	O - RING
114*	BTP11399-0460002-1	COLLAR
115	BTP1132M-0254705-1	PACKING
116	BTP1131E-0080001-2	CYLINDER PRESS RING
117*	BTP11350-0460601-1	PISTON RING
118	BTP2041102-04040-0	O - RING
119	BTP11204-0250021-2	DRIVER UNIT
120	BTP11320-0252401-1	CYLINDER
121	BTP2041100-05050-0	O - RING
122	BTP11321-0250006-1	CYLINDER SPACER
123	BTP2041104-07030-0	O - RING
124	BTP11322-0250001-1	CYLINDER RING
125*	BTP11327-0084702-1	BUMPER
201	BTP2041104-02020-0	O - RING
202	BTP2041104-02030-0	O - RING
203	BTP11374-0084701-1	PLUNGER CAP
204	BTP1133S-0250001-1	VALVE PLUNGER
205	BTP2041100-01070-0	O - RING
206	BTP2041100-01030-0	O - RING
207	BTP11376-0254701-1	SPRING
208	BTP11375-0080002-1	PLUNGER
209	BTP2041102-01030-0	O - RING
210	BTP11373-0084701-1	TRIGGER VALVE HEAD
211	BTP2040400-05060-0	SPRING PIN
212	BTP2040400-05160-0	SPRING PIN
213	BTP2040400-05120-0	SPRING PIN
214	BTP11224-0764701-1	TRIGGER UNIT

ITEM	PARTS NO	PARTS NAME
215	BTP11376-0370001-1	SPRING
216	BTP11318-0374701-1	TRIGGER PIVOT PIN
217	BTP1131D-0460001-1	URETHANE RETAINER
301	BTP11230-0255207-1	GUN BODY
302	BTP2040300-03010-0	C - RING
303	BTP1137N-0250001-1	FILTER
304	BTP11346-0251308-1	END CAP
305	BTP2041109-05050-0	O - RING
308	BTP1135V-0000023-1	AIR PLUG
401	BTP11382-0254704-2	NOSE PIECE
402	BTP2041102-01040-0	O - RING
403	BTP2041109-04010-0	O - RING
404	BTP2040101-03090-2	HEX.SOC.HD.BOLT
405	BTP11306-0254704-1	FEED FINGER
406	BTP11364-0254704-1	FEED PISTON
407	BTP11365-0664701-1	PIN FEED PISTON
408*	BTP11307-0250001-1	FEED FINGER SPRING
409	BTP1135H-0790001-1	PU RETAINER
410*	BTP2041109-01050-0	O - RING
411*	BTP2041105-02060-0	O - RING
412	BTP1133F-0250002-1	FEED PISTON SPRING
413	BTP1134W-0250003-1	FEED-BUMPER
414	BTP11366-0254705-1	FEED PISTON CAP
415	BTP2040100-02040-2	BOLT ASSY
417	BTP1130D-0250001-1	SPRING
418	BTP1138J-0250001-1	GUIDE BLOCK SPRING
420*	BTP1135D-0254702-1	GUIDE BLOCK
421	BTP2041104-01040-0	O - RING
422	BTP11324-0254702-1	FIXED PIN
424	BTP11361-0254704-1	DOOR
425	BTP11310-0254702-2	LOCK LEVER
426	BTP11311-0254703-1	LATCH SPRING
430	BTP1133C-0784701-1	STOPPER FINGER SPRING
434	BTP11362-0814701-1	DOOR SHAFT PIN
435	BTP11338-0254706-1	SAFETY GUIDE
436	BTP2040400-04050-0	SPRING PIN
437	BTP11337-0084701-1	SAFETY SPRING
438	BTP11256-0764702-2	SAFETY B UNIT
439	BTP11393-0767802-1	ADJUST AXIE

ITEM	PARTS NO	PARTS NAME
440	BTP1137A-0254702-1	SAFETY COVER
441	BTP11393-0254705-1	ADJUST ROD
442	BTP2041102-01050-0	O - RING
443	BTP11257-0254701-1	SAFETY UNIT
444	BTP2040302-23010-0	E - RING
448	BTP11354-0254701-1	MAGAZINE CASE
449	BTP2040500-04010-0	LOCK NUT
452	BTP11355-0254701-2	MAGAZINE COVER
459	BTP11356-0250001-2	NAIL HOLDER
460	BTP2040107-02050-0	TAP BOLT
475	BTP1130G-0254703-1	FIRST STOPPER FINGER
476	BTP1130C-0254702-1	SECOND STOPPER FINGER
478	BTP11359-0784702-1	PIN-NAIL STOP
479	BTP2040400-05090-0	SPRING PIN
480	BTP1134N-0254701-1	SPRING BASE A
481	BTP11328-0254701-1	PULL SPRING
482	BTP2041100-01040-0	O - RING
483	BTP1132V-0254702-1	PIN
484	BTP11357-0250001-1	ADJUST POST
485	BTP1135P-0254702-1	PROTECTION UNIT
486	BTP2040201-04020-0	FLAT WASHER
487	BTP2040101-04090-0	HEX.SOC.HD.BOLT
488	BTP1134M-0250002-1	SPRING BASE
489	BTP11398-0254702-1	LATCH SPRING BUSHING
490	BTP1132U-0254703-1	MAGAZING GUARD
491	BTP2040100-04010-0	BOLT ASSY
492	BTP1130X-0254702-1	ADJUSTING UNT
493	BTP11312-0254704-1	ADJUSTING PLATE
494	BTP2040101-04010-0	HEX.SOC.HD.BOLT

The following parts are included in the BTPCNR45KIT1 parts kit:

110	113	115	121	124	411
112	114	117	123	410	413

The following parts are included in the BTPCNR45KIT2 parts kit:

201	203	205	207	209	211
202	204	206	208	210	