



BT-FLN1650

ITEM	PARTS NO	PARTS NAME
101	BTP11371-0854701-1	DEFLECTOR
102	BTP2040100-04020-1	BOLT ASSY
103	BTP11369-0855201-1	CAP
104*	BTP2041104-03040-0	O - RING
105	BTP1136M-0850001-1	SAFETY STOPPER
106	BTP11337-0254704-1	SAFETY SPRING
107	BTP2040101-03110-7	HEX.SOC.HD.BOLT
108	BTP11368-0850002-1	HD.VALVE PISTON
109*	BTP2041108-06030-0	O - RING
110	BTP11380-0850001-1	CAP GASKET
111*	BTP11380-0850002-2	GASKET
112*	BTP1139J-0850001-2	DISCHARGE SHEET
113*	BTP2041104-02111-0	O - RING
114*	BTP11399-0850001-1	COLLAR
115*	BTP1139H-0850002-1	PISTON SHAFT
116*	BTP11329-0854701-1	PIN
117*	BTP11349-1320001-1	MAIN PISTON
118*	BTP2041108-06100-0	O - RING
119*	BTP11387-0850001-1	DRIVER
120*	BTP1134S-1324701-1	FIRING PIN DRAWBAR
121*	BTP11327-0854701-1	BUMPER
201	BTP2040101-02020-1	HEX.SOC.HD.BOLT
202	BTP113AR-0850001-1	Steel Cable
203	BTP11316-0854701-1	TRIGGER
204	BTP2040403-06040-0	PIN
206	BTP11398-0854701-1	LATCH SPRING BUSHING
301	BTP11384-0855204-1	GUN BODY
302	BTP1137K-0851302-1	HANDLE
303	BTP1137K-0851301-1	HANDLE A
304	BTP2040100-04010-0	BOLT ASSY
305	BTP1135V-0000010-1	AIR PLUG
306	BTP2040101-04090-1	HEX.SOC.HD.BOLT
307	BTP2040403-08090-0	PIN
401	BTP2040101-03040-1	HEX.SOC.HD.BOLT
402	BTP11326-0854701-2	BASE
403	BTP2040101-03070-2	HEX.SOC.HD.BOLT
404	BTP2040400-05320-0	SPRING PIN
405	BTP2040400-05060-0	SPRING PIN
406	BTP11351-0850001-1	DRIVER GUIDE COVER

ITEM	PARTS NO	PARTS NAME
407	BTP11303-0854703-1	DRIVER GUIDE
408	BTP11389-0854703-1	MAGAZINE A
409	BTP11396-0850001-1	STEEL CHANNEL
410	BTP1136E-0854701-1	PROTECTING HOOD COVER
411	BTP1138H-0460001-1	PUSHER SPRING
412	BTP11363-0854701-1	PUSHER
413*	BTP11372-0070001-1	SPRING
414	BTP2040401-05110-0	SPIRAL PINS
415	BTP1131G-0850001-1	FIXED RING
416	BTP2040101-02181-0	HEX.SOC.HD.BOLT
417	BTP2040500-02010-0	LOCK NUT
418	BTP1136H-0851302-1	FIXED SUPPORT
419	BTP1135R-0850003-2	PROTECTIVE CUSHION
420	BTP2040103-04090-0	COUNTER SUNK SCREW
421	BTP2040101-04111-2	HEX.SOC.HD.BOLT
422	BTP1134L-0084701-1	BRACKET
423	BTP2040302-23010-0	E - RING
425	BTP2040101-02040-2	HEX.SOC.HD.BOLT
426	BTP11397-0854701-1	GUIDE COVER
427	BTP2040101-03110-2	HEX.SOC.HD.BOLT
428	BTP2040501-04010-0	BOLT CAP
429	BTP11337-0374701-1	SAFETY SPRING
431	BTP1139M-0850002-2	HAMMER

The following parts are included in the BTPFLKIT1 parts kit:

104	111	114
109	113	118