



BT-FLS9040

ITEM	PARTS NO	PARTS NAME
101	BTP11371-0394701-3	DEFLECTOR
102	BTP11369-0685201-1	CAP
103	BTP11370-0010003-1	SEAL
104	BTP11360-0010001-3	COMPRESSION SPRING
105	BTP2041100-02020-0	O - RING
106	BTP2041108-04010-0	O - RING
107	BTP11368-0150001-1	HD.VALVE PISTON
108	BTP2041108-03120-0	O - RING
109	BTP11302-0024701-1	CYLINDER CAP SEAL
110	BTP2040100-02070-0	BOLT ASSY
111*	BTP11350-0010002-1	PISTON RING
112*	BTP11204-1240001-1	DRIVER UNIT
113	BTP2041105-03020-0	O - RING
114	BTP2041109-05060-0	O - RING
115	BTP11320-0682401-1	CYLINDER
116	BTP11322-0010001-1	CYLINDER RING
117*	BTP11327-0314701-3	BUMPER
118	BTP11301-1240001-1	JOINT GUIDE
119	BTP2040100-02100-0	BOLT ASSY
201	BTP2041102-01020-0	O - RING
202	BTP11373-0150001-3	TRIGGER VALVE HEAD
203	BTP1133U-0014701-1	SPRING
204	BTP11375-0154701-1	PLUNGER
205	BTP2041102-01030-0	O - RING
205A	BTP2041102-01031-0	O - RING
206	BTP2041109-02030-0	O - RING
207	BTP11374-0154701-1	PLUNGER CAP
208	BTP2040400-05110-0	SPRING PIN
209	BTP11317-0154702-1	SECONDARY TRIGGER
210	BTP11316-0154701-1	TRIGGER
211	BTP2040400-04110-0	SPRING PIN
212	BTP2040400-04070-0	SPRING PIN
213	BTP11376-0154701-1	SPRING
301	BTP11230-0395203-3	GUN BODY UNIT
302	BTP11346-0151301-1	END CAP
303	BTP2041109-04060-0	O - RING
305	BTP1135V-0000022-1	AIR PLUG
401	BTP2040111-03010-0	SCREW
402	BTP1136H-1244701-1	FIXED SUPPORT

ITEM	PARTS NO	PARTS NAME
403	BTP11334-1244701-1	RELIEF PLATE
404	BTP1135R-1244701-1	PROTECTIVE CUSHION
405	BTP2040103-02080-0	COUNTER SUNK SCREW
406	BTP11351-1244701-1	DRIVER GUIDE COVER
407	BTP11380-0684702-1	GASKET
408	BTP11363-0684703-2	PUSHER
409	BTP11378-0224701-1	SHAFT
410	BTP11367-0024701-1	PUSHER SPRING
411	BTP11347-0684701-1	REAR PLATE
412	BTP11343-0394704-1	LATCH
413	BTP11344-0394705-1	LATCH PIN
414	BTP11315-0260001-1	SPRING
415	BTP11305-0024701-1	STOPPER
416	BTP2040302-23010-0	E - RING
417	BTP2040101-02110-0	HEX.SOC.HD.BOLT
418	BTP2040500-02010-0	LOCK NUT
419	BTP11330-1244701-1	SAFETY
420	BTP11311-0104701-1	LATCH SPRING
421	BTP11338-0024702-1	SAFETY GUIDE
422	BTP11389-0684701-2	MAGAZINE A
423	BTP11391-0684701-2	MAGAZINE B
424	BTP2040107-01040-0	TAP BOLT
425	BTP1136J-1244701-1	HAND UNT
426	BTP2040100-03040-2	BOLT ASSY

The following parts are included in the BTPFLS9040KIT1 parts kit:

105	108	111	114
106	109	113	116