



BT-CNP70PAL

ITEM	PARTS NO	PARTS NAME
101	BTP2040101-04111-2	HEX.SOC.HD.BOLT
102	BTP11369-0865201-1	CAP
103	BTP1135S-0350001-1	GROMMET
104	BTP2040104-03010-0	HEX.SOC.HD.SCREW
105	BTP11397-0864701-1	GUIDE COVER
106	BTP11302-0864701-1	CYLINDER CAP SEAL
107	BTP11370-0860001-1	SEAL
108	BTP11360-0354701-3	COMPRESSION SPRING
109	BTP2041108-05070-0	O - RING
110	BTP11381-0864701-1	WASHER
111	BTP11368-0860001-3	HD.VALVE PISTON
112	BTP2041108-06050-0	O - RING
113	BTP2041108-05060-0	O - RING
114	BTP11204-0860003-2	DRIVER UNIT
115	BTP11399-0860001-1	COLLAR
116	BTP11320-0860001-1	CYLINDER
117	BTP2041108-06010-0	O - RING
118	BTP11321-0860001-1	CYLINDER SPACER
119	BTP2041101-09020-0	O - RING
120	BTP2041100-06010-0	O - RING
121	BTP11327-0864701-1	BUMPER-A
122	BTP11327-0864702-1	BUMPER-B
123	BTP1135S-0860001-1	GROMMET A
124	BTP11362-0864701-1	DOOR SHAFT PIN
201	BTP2041104-02060-0	O - RING
202	BTP11374-0860002-1	PLUNGER CAP
203	BTP2041100-02050-0	O - RING
204	BTP2041100-01070-0	O - RING
205	BTP1133S-0860002-1	VALVE PLUNGER
206	BTP2041100-01030-0	O - RING
207	BTP11376-0860002-1	SPRING
210	BTP11373-0860003-1	TRIGGER VALVE HEAD
211	BTP11329-0860002-1	PIN
214	BTP2041100-01051-0	O - RING
206	BTP2041100-01030-0	O - RING
207	BTP11376-0860002-1	SPRING
210	BTP11373-0860003-1	TRIGGER VALVE HEAD
211	BTP11329-0860002-1	PIN
214	BTP2041100-01051-0	O - RING

ITEM	PARTS NO	PARTS NAME
215	BTP2040401-05100-0	SPIRAL PINS
218	BTP2040401-05080-0	SPIRAL PINS
219	BTP2040401-05120-0	SPIRAL PINS
221	BTP2041423-51040-0	L TYPE AIR PLUG
301	BTP11230-0865201-1	GUN BODY UNIT
302	BTP2041101-05020-0	O - RING
303	BTP11346-0861304-1	END CAP
304	BTP1132L-0350001-1	AIR PLUG CAP
305	BTP1135V-0000009-1	AIR PLUG
401	BTP2041108-06060-0	O - RING
402	BTP2041108-01010-0	O - RING
403	BTP11382-0864702-1	NOSE PIECE
404	BTP2040101-05040-1	HEX.SOC.HD.BOLT
405	BTP2041100-01091-0	O - RING
406	BTP11364-0864701-1	FEED PISTON
407	BTP2041100-03051-0	O - RING
408	BTP1134W-0860001-1	FEED BUMPER
409	BTP11367-0860001-1	PUSHER SPRING
410	BTP11366-0864701-1	FEED PISTON CAP
411	BTP2040300-02010-0	C - RING
413	BTP11310-0954701-1	DOOR LATCH
414	BTP11311-0860001-1	LATCH SPRING
415	BTP11361-0864702-1	DOOR
416	BTP1135H-0860001-1	PU RETAINER
417	BTP2040400-05060-0	SPRING PIN
418	BTP1133C-0860001-1	STOPPER FINGER SPRING
419	BTP11358-0864701-1	NAIL STOP
420	BTP11359-0864701-1	PIN-NAIL STOP
435	BTP11365-0864701-1	PIN FEED PISTON
436	BTP11306-0864701-1	FEED FINGER
437	BTP11307-0864701-1	FEED FINGER SPRING
444	BTP2040200-06011-0	SPRING WASHER
445	BTP11367-0974702-1	PUSHER SPRING

The following parts are including in the CNP70PALKIT1 parts kit:

106	109	110	112	113	115	117
119	120					

The following parts are including in the CNPPALKIT2 parts kit:

201	202	203	204	205	206	207
210	211	214	221			