



ITEM	PARTS NO	PARTS NAME
101	BTP2040101-04111-2	HEX.SOC.HD.BOLT
102	BTP11369-0865201-1	CAP
103	BTP1135S-0350001-1	GROMMET
104	BTP2040104-03010-0	HEX.SOC.HD.SCREW
105	BTP11397-0864701-1	GUIDE COVER
106	BTP11302-0864701-1	CYLINDER CAP SEAL
107	BTP11370-0860001-1	SEAL
108	BTP11360-0354701-3	COMPRESSION SPRING
109	BTP2041108-05070-0	O - RING
110	BTP11381-0864701-1	WASHER
111	BTP11368-0860001-3	HD.VALVE PISTON
112	BTP2041108-06050-0	O - RING
113	BTP2041108-05060-0	O - RING
114	BTP11204-0860003-2	DRIVER UNIT
115	BTP11399-0860001-1	COLLAR
116	BTP11320-0860001-1	CYLINDER
117	BTP2041108-06010-0	O - RING
118	BTP11321-0860001-1	CYLINDER SPACER
119	BTP2041101-09020-0	O - RING
120	BTP2041100-06010-0	O - RING
121	BTP11327-0864701-1	BUMPER-A
122	BTP11327-0864702-1	BUMPER-B
123	BTP1135S-0860001-1	GROMMET A
124	BTP11362-0864701-1	DOOR SHAFT PIN
201	BTP2041104-02060-0	O - RING
202	BTP11374-0860001-1	PLUNGER CAP
203	BTP2041100-02050-0	O - RING
204	BTP2041100-01070-0	O - RING
205	BTP1133S-0860001-1	VALVE PLUNGER
206	BTP2041100-01030-0	O - RING
207	BTP11376-0860001-1	SPRING
208	BTP2041108-01020-0	O - RING
209	BTP11375-0860002-1	PLUNGER
210	BTP11373-0860001-1	TRIGGER VALVE HEAD
211	BTP11329-0860001-1	PIN
212	BTP1137A-0860001-1	COVER-PLUNGER
213	BTP2041104-02070-0	O - RING
214	BTP2041100-01050-0	O - RING
215	BTP2040401-05100-0	SPIRAL PINS

ITEM	PARTS NO	PARTS NAME
216	BTP11317-0864701-2	SECONDARY TRIGGER
217	BTP11316-0864701-3	TRIGGER
218	BTP2040401-05080-0	SPIRAL PINS
219	BTP2040401-05120-0	SPIRAL PINS
301	BTP11230-0865201-1	GUN BODY UNIT
302	BTP2041101-05020-0	O - RING
303	BTP11346-0861304-1	END CAP
304	BTP1132L-0350002-1	AIR PLUG CAP
305	BTP1135V-0000010-1	AIR PLUG
401	BTP2041108-06060-0	O - RING
402	BTP2041108-01010-0	O - RING
403	BTP11382-0864702-1	NOSE PIECE
404	BTP2040101-05040-1	HEX.SOC.HD.BOLT
405	BTP2041100-01091-0	O - RING
406	BTP11364-0864701-1	FEED PISTON
407	BTP2041100-03051-0	O - RING
408	BTP1134W-0860001-1	FEED BUMPER
409	BTP11367-0860001-1	PUSHER SPRING
410	BTP11366-0864701-1	FEED PISTON CAP
411	BTP2040300-02010-0	C - RING
412	BTP2040101-04131-0	HEX.SOC.HD.BOLT
413	BTP11310-0954701-1	DOOR LATCH
414	BTP11311-0860001-1	LATCH SPRING
415	BTP11361-0864702-1	DOOR
416	BTP1135H-0860001-1	PU RETAINER
417	BTP2040400-05060-0	SPRING PIN
418	BTP1133C-0860001-1	STOPPER FINGER SPRING
419	BTP11358-0864701-1	NAIL STOP
420	BTP11359-0864701-1	PIN-NAIL STOP
421	BTP11383-0860001-1	MUZZLE PROTECTOR
422	BTP1134B-0864701-1	DUST SHIELD PLUG
423	BTP11330-0864702-1	SAFETY
424	BTP11337-0864701-1	SAFETY SPRING
425	BTP11338-0864701-2	SAFETY GUIDE
426	BTP11354-0864701-3	MAGAZINE CASE
427	BTP11357-0860001-4	ADJUST POST
428	BTP2040301-24010-0	C - RING
429	BTP1134M-0864701-1	SPRING BASE
431	BTP11259-0864701-1	NAIL BRACKET UNIT

ITEM	PARTS NO	PARTS NAME
432	BTP1138W-0860001-1	SPACER
433	BTP11328-0860001-1	PULL SPRING
434	BTP11355-0864703-1	MAGAZINE COVER
435	BTP11365-0864701-1	PIN FEED PISTON
436	BTP11306-0864701-1	FEED FINGER
437	BTP11307-0864701-1	FEED FINGER SPRING
438	BTP2040101-04121-2	HEX.SOC.HD.BOLT
439	BTP1135U-1010001-1	PROTECTOR WASHER
441	BTP1134R-0864701-1	SPRING COVER
442	BTP2040501-04010-0	BOLT CAP
443	BTP1136R-0864701-1	MAGAZINE SHAFT PIN
444	BTP2040200-06011-0	SPRING WASHER

The following parts are including in the CNP70KIT1 parts kit:

106	109	110	112	113	115	117
119	120					

The following parts are including in the CNPKIT2 parts kit:

201	202	203	204	205	206	207
208	208	209	210	211	211	212
213	214					