



BT-CNP80

ITEM	PARTS NO	PARTS NAME
101	BTP1137V-0954701-1	DEFLECTOR BLOT(3M2353)
102	BTP11381-0954703-1	WASHER
104	BTP11371-0954702-2	DEFLECTOR
106	BTP1135S-0350001-1	GROMMET
107	BTP11369-0975201-1	CAP
108	BTP2040104-03010-0	HEX.SOC.HD.SCREW
109	BTP2040101-04110-2	HEX.SOC.HD.BOLT
110*	BTP11302-0864701-1	CYLINDER CAP SEAL
111	BTP11381-0970001-1	WASHER SEAL
112*	BTP11370-0970001-1	SEAL
113	BTP11360-0354701-3	COMPRESSION SPRING
114	BTP11381-0864701-1	WASHER
115*	BTP2041108-05070-0	O - RING
116	BTP11368-0970001-2	HD.VALVE PISTON
117*	BTP2041108-06050-0	O - RING
118*	BTP2041108-05060-0	O - RING
119*	BTP11204-0970003-1	DRIVER UNIT
120*	BTP11399-0860001-1	COLLAR
121	BTP11320-0970001-1	CYLINDER
122	BTP2041108-06010-0	O - RING
123	BTP11321-0860001-1	CYLINDER SPACER
124	BTP2041101-09020-0	O - RING
125	BTP2041100-06010-0	O - RING
126*	BTP11327-0864701-1	BUMPER-A
127*	BTP11327-0864702-1	BUMPER-B
128	BTP1135S-0860001-1	GROMMET A
129	BTP11362-0864701-1	DOOR SHAFT PIN
130	BTP11397-0974701-1	GUIDE COVER
131	BTP1132T-0780001-1	MUFFLER
201	BTP2041104-02060-0	O - RING
202	BTP11374-0860001-1	PLUNGER CAP
203	BTP2041100-02050-0	O - RING
204	BTP2041100-01070-0	O - RING
205	BTP1133S-0860001-1	VALVE PLUNGER
206	BTP2041100-01030-0	O - RING
207	BTP11376-0860001-1	SPRING
208	BTP2041108-01020-0	O - RING
209	BTP11375-0860002-1	PLUNGER
210	BTP11373-0860001-1	TRIGGER VALVE HEAD

ITEM	PARTS NO	PARTS NAME
211	BTP11329-0860001-1	PIN
212	BTP1137A-0860001-1	COVER-PLUNGER
213	BTP2041104-02070-0	O - RING
214	BTP2041100-01050-0	O - RING
215	BTP2040401-05100-0	SPIRAL PINS
216	BTP11317-0864701-2	SECONDARY TRIGGER
217	BTP11316-0864701-3	TRIGGER
218	BTP2040401-05080-0	SPIRAL PINS
219	BTP2040401-05120-0	SPIRAL PINS
301	BTP11230-0975201-1	GUN BODY UNIT
302	BTP2041101-05020-0	O - RING
303	BTP11346-0861304-1	END CAP
304	BTP1132L-0350002-1	AIR PLUG CAP
305	BTP1135V-0000010-1	AIR PLUG
401	BTP2041108-06060-0	O - RING
402	BTP2041108-01010-0	O - RING
403	BTP11382-0974702-1	NOSE PIECE
404	BTP2040101-05040-1	HEX.SOC.HD.BOLT
405*	BTP2041100-01090-0	O - RING
406	BTP11364-0974703-1	FEED PISTON
407*	BTP2041100-03051-0	O - RING
408	BTP1134W-0860001-1	FEED BUMPER
410	BTP11367-0860001-1	PUSHER SPRING
411	BTP11366-0864701-1	FEED PISTON CAP
412	BTP2040300-02010-0	C - RING
413	BTP2040101-04251-0	HEX.SOC.HD.BOLT
414	BTP11310-0954701-1	DOOR LATCH
415	BTP11311-0860001-1	LATCH SPRING
416	BTP11361-0974702-1	DOOR
417	BTP1135H-0860001-1	PU RETAINER
418	BTP2040400-05060-0	SPRING PIN
419	BTP1133C-0860001-1	STOPPER FINGER SPRING
420	BTP11358-0864701-1	NAIL STOP
421	BTP11359-0864701-1	PIN-NAIL STOP
422	BTP11330-0974703-1	SAFETY
423	BTP11337-0864701-1	SAFETY SPRING
424	BTP11338-0864701-2	SAFETY GUIDE
425	BTP11354-0974702-1	MAGAZINE CASE
426	BTP11357-0954701-1	MAGAZINE POST

ITEM	PARTS NO	PARTS NAME
421	BTP11359-0864701-1	PIN-NAIL STOP
422	BTP11330-0974703-1	SAFETY
423	BTP11337-0864701-1	SAFETY SPRING
424	BTP11338-0864701-2	SAFETY GUIDE
425	BTP11354-0974702-1	MAGAZINE CASE
426	BTP11357-0954701-1	MAGAZINE POST
427	BTP1138Y-0954701-2	RUBBER RING
428	BTP1134M-0864701-1	SPRING BASE
429*	BTP11356-0974701-1	NAIL HOLDER
430	BTP1138W-0860001-1	SPACER
431	BTP11328-0860001-1	PULL SPRING
432	BTP11355-0974703-1	MAGAZINE COVER
433	BTP11365-0864701-1	PIN FEED PISTON
434	BTP11306-0974702-1	FEED FINGER
436*	BTP11307-0864701-1	FEED FINGER SPRING
437	BTP2040101-04121-0	HEX.SOC.HD.BOLT
438	BTP1134R-0974701-1	SPRING COVER
439	BTP2040501-04010-0	BOLT CAP
440	BTP1136R-0864701-1	MAGAZINE SHAFT PIN
441	BTP1134N-1014701-1	SPRING BASE A
442*	BTP11383-0970001-1	MUZZLE PROTECTOR
443	BTP1135U-1010001-1	PROTECTOR WASHER
444	BTP1134B-0864701-1	DUST SHIELD PLUG
446	BTP2040200-06011-0	SPRING WASHER

The following parts are including in the CNP80KIT1 parts kit:

110	111	114	115	117	118	120
122						

The following parts are including in the CNPKIT2 parts kit:

201	202	203	204	205	206	207
208	208	209	210	211	211	212
213	214					